



# MAPSMART®

## FOR ANDROID

# QUICK START GUIDE

The quick reference guide instructions are sectioned by specific LTI lasers as used with a ruggedized Android tablet (shown below).



For other Android tablets, set up may be different. Refer to your device's manual for more information on connecting to Wifi, email accounts, and Bluetooth® enabled devices.



TruPulse® 360°/B survey laser (yellow);  
TruPulse® 360° R survey laser (black)



TruPulse® 200X survey laser (red)

















TruPoint™ 300 survey laser (red)



Tablet running Android 4.1 or later



# [1<sup>st</sup> Step for All] WLAN, MapSmart App, Licensing:



- [1] Turn on tablet, tap  Settings, tap  Display to set SLEEP to NEVER.
- [2] Tap  WLAN to select a wifi network and complete process.
- [3] Tap  Settings then tap  Add account to add a Google account or get assistance from your IT department to set up a dedicated email account for your reports.
- [4] Tap , then Search for: “LaserSoft MapSmart”  and INSTALL the app.
- [5] From the main screen, tap , then tap  to open app.
- [6] Tap and hold Machine ID: 748DDB3C to copy or notate Machine ID on paper.
- [7] Tap [License Manager website](#) link, then log in with your email and temporary password sent from LTI.
- [8] Paste or type the Machine ID into .
- [9] From the Purchases Table, copy and paste or type in your purchase ID into .
- [10] Tap , then copy or notate the License Key. [11] Tap , then paste or type in the License Key and then tap . [12] Charge tablet. [13] Go to [2nd Step] depending upon your laser set up: TruPulse 360B/R, TruPulse 200X + TruAngle, or TruPoint 300.

## [2<sup>nd</sup> Step for TruPulse 360B/R] Toggle On *Bluetooth* Link:



[1] Press  to power the unit on. [2] Long press  until (Units).



[3] Press  until (bt). [4] Press  then press  until (bt on).



[5] Press  to confirm.

## [3<sup>rd</sup> Step] Change Units of Measure to Feet (if necessary):

[1] Long press  until (Units).

[2] Press  then press  until (**FEET**). [3] Press , then press  again to accept feet/degrees and units of measurement.

## [4<sup>th</sup> Step] Connect TruPulse 360B/R with Android Device:

[1] Tap  Settings, then tap  Bluetooth. [2] Turn on tablet *Bluetooth* link.













[3] Tap the laser model/serial number under AVAILABLE DEVICES.

[4] Enter PIN number: 1111 or accept any passkey. [5] Exit to main screen.









## [Final Step for TruPulse 360B/R] Set Up & Get a Shot:

\*For standard survey with no GPS or Resection options selected.








- [1] Power on all components.
- [2] Perform the laser compass calibration routine.
- [3] Tap , then tap .
- [4] Enter file name, then tap  and select equipment.
- [5] Tap , then select units that match the laser.
- [6] Measure from center of laser to ground and enter value .
- [7] Measure from center of prism to ground and enter value , then tap . Leave value 0.00 if not using a prism.
- [8] Leave all origin values at zero (unless known equipment position) and tap .
- [9] Wait for  to become  at the top of the MapSmart screen.
- [10] Aim and press  on the laser and add the first data point.
- [11] Enter a description and tap .
- [12] Finish the survey.

## [2<sup>nd</sup> Step for TruPulse 200X + TruAngle] Toggle On *Bluetooth* link:









[1] Press  to power the unit on. [2] Press  until (  ). [3] Press  until (  ). [4] Press  to accept.



## [3<sup>rd</sup> Step] Change Units of Measure to Feet (if necessary):

[1] Press  until (  ). [2] Press  to scroll through unit options (  ) or (  ). [3] Press  to accept the units of measurement (  ).

## [4<sup>th</sup> Step] Toggle On Electronic Filter (if using a reflective target):

[1] Press  until (  ). [2] Press  to choose (  ). [3] Press  to accept selection. [4] Apply the mechanical filter  to the front lens.


















## [5<sup>th</sup> Step] Sync Tablet's *Bluetooth* link with TruPulse 200X:

[1] Tap  Settings, then tap  Bluetooth. [2] Turn on tablet *Bluetooth* link. [3] Tap the laser model/serial number under AVAILABLE DEVICES. [4] Enter the PIN number: 1234 or accept any passkey. [5] Exit to main screen.



## [Final Step for TruPulse 200X] Set Up & Get a Shot:

\*For standard survey with no GPS or Resection options selected.

- [1] Power on all components. [2] Tap , then tap .
- [3] Enter file name, then tap  and select equipment.
- [4] Tap , then select Units that match the laser.
- [5] Measure from center of laser to ground and enter value .
- [6] Measure from center of prism to ground and enter value , then tap . Leave value 0.00 if not using a prism.
- [7] Leave all origin values at zero and tap .
- [8] On TruAngle, rotate 360 degrees until  becomes flashing .
- [9] Aim laser at desired reference point (or prism), then tighten the TruAngle brake  and press  on laser and  stops flashing.
- [10] Press  again to add the reference data point to your map. [11] Enter “REF” for the description and tap . Notice that  turns into  at the top of the MapSmart screen. Tap to refresh connection if necessary [12] Finish the survey.

## [2<sup>nd</sup> Step for TruPoint 300] Activate WLAN:




[1] Press  to power the unit on. [2] Press , then tap .



[3] Tap  twice, then activate WLAN connectivity . [4] Press  to accept.

## [3<sup>rd</sup> Step] Change Units of Measure to Feet (if necessary):

[1] Press  then tap . [2] Tap  twice, then change unit of measurement.

[3] Short press  to return to the main screen.

## [4<sup>th</sup> Step] Connect TruPoint 300 to Tablet:

[1] Tap  Settings, then tap .

[2] Tap the laser model/serial number listed in available networks.

[3] Laser will display as connected.





## [Final Step for TruPoint 300]Set Up & Get A Shot:

\*For standard survey with no GPS or Resection options selected.

[1] Power ON all components. [2] Check tablet settings to verify TruPoint is connected.


[3] Tap , then tap .

[4] Enter file name, then tap  and select equipment.




[5] Enter Units that match the laser.

[6] Measure from center of laser to ground and enter value .

[7] If using a non-reflective target, measure center of target to ground and enter value

, then tap . If not using a target, leave value at 0.00

[8] Tap , wait until the icon becomes . [9] On TruPoint, follow leveling directions.

[10] On tablet, leave all origin values at zero and tap . [11] Aim laser at desired reference point (target), then tap  to zero laser, and tap .

[12] Tap  to add the reference data point to your map.

[13] Enter “REF” for the description and tap . [14] Finish the survey.



## Access MapSmart Help:

[1] Tap  and choose Help.

Get help with:

- Laser/tablet *Bluetooth* connection or WLAN connection
  - \*Low voltage on tablet or laser can hinder wireless connections.
  - \*\*Pair laser to only one device at a time.
- Available mapping methods
- Corrections to data point heights, notes, and orientation
- Moving control point and equipment to a new position
- Converting inches to decimal feet for height entries
- Sending program diagnostics and/or survey \*.MS4D file to LTI technical support (while on WiFi only).

# Radial with Angle Mapping Package Assembly for TruPoint 300

TruPoint™ 300  
#7006880



Laser Aiming Assist  
#3255094



Claw Mounting Base  
#3255097



CT7 Ruggedized  
Android Tablet  
#3255095



Tripod  
#3504683




X Grip for 7" Tablets  
#3255096





# Radial with Angle Mapping Package Assembly for TP360R



TruPulse® 360R

Mounting  
Bracket  
#7024866  
(optional)

TruPulse® 360/B,  
laser may be  
substituted along  
with bracket  
#7024736

Yoke L Bracket  
#7024746  
(optional)

Cedar CT7  
Data Collector  
#3255095

Data Collector  
Cradle Clamp  
#3504631

Cedar Tablet  
MapSmart  
with Volume  
Package  
#3210009

LTI Staff  
and  
Bi-Pod Legs  
#3504272

7 in. Tablet  
X-Grip Cradle  
#3255096

Laser to Data  
Collector  
Download Cable  
#3255067  
(Optional if  
Bluetooth not  
available)



**LTI Technical Support:**

Toll Free: 1.877.696.2584

Phone: 1.303.649.1000

Email: [support@lasertech.com](mailto:support@lasertech.com)

Web: [www.lasertech.com](http://www.lasertech.com)

**LTI Hours of Operation:**

Monday through Friday

8:00 am to 5:00 pm (MST)

(Excluding Holidays)



**LTI Corporate Headquarters:**

6912 South Quentin Street

Centennial, CO 80112 USA

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Laser Technology, Inc. is under license. Other trademarks and trade names are those of their respective owners.