Instructions for using TRE_ARM to free up the Bluetooth COM Ports

1. Download the TRE.ARM.CAB file to your PC.

2. Copy/paste the CAB file to the Program Files folder on the Nomad.

3. Open File Explorer on the Nomad and open the Program Files folder.

4. Tap on the file named TRE_ARM.CAB to run (install) the program.

5. The Tre Arm Program should now be visible in the Programs list. Tap it to launch the program.

6. Navigate to the following folder:
   HKEY_LOCAL_MACHINE\Software\Microsoft\Bluetooth\Serial\Ports\

7. Delete anything below the level above, that is, delete anything in the Ports folder.

8. Close the Register Editor Program.

9. Perform a shutdown on the Nomad by holding the Power button for 3 sec and then release. Choose Shutdown from the Power menu.

10. Re-pair the Bluetooth Device and the COM ports that were unavailable before (COM 8 and 9) should now work.